


# Keekaroo SNOOZER™

## Harness Instructions:



Place child face-up in Snoozer™. Position the Crotch Strap between child's legs then bring both Lap Straps around child's waist and "CLICK" into Crotch Strap Buckle. Adjust length of Lap Straps to secure child in Snoozer™.

NOTE: Press center button on Crotch Strap Buckle to release child.



## Product Notes

The Keekaroo Snoozer™ product has been designed and tested to ensure compliance with the latest relevant safety standards. Refer to all warning instructions below for proper use. Warning: Strings can cause strangulation! Do not place items with a string around a child's neck, such as hood strings or pacifier cords. Do not suspend strings over product or attach strings to toys.

## Product Care

Use a mild detergent to clean periodically. Keekaroo Snoozer™ is impermeable to fluids, however, DO NOT SUBMERGE while cleaning. Ensure Keekaroo Snoozer™ is completely dry after cleaning.

## ▲WARNING:

Failure to follow these warnings and the instructions could result in serious injury or death.

**FALL HAZARD** - To prevent falls, stop using the product when infant:

- (1) Begins to roll over, or
- (2) Can pull up on sides (approximately 5 months).
- ALWAYS use on floor. Never use on any elevated surface.
- ALWAYS use restraint system.

**SUFFOCATION HAZARD** - Infants have suffocated:

- (1) On added pillows, blankets and extra padding.
  - ONLY use the pad provided by the manufacturer.
  - NEVER place extra padding under or beside infant.
- (2) When trapped between product and adjacent surface.
  - NEVER use inside cribs, play yards or other products.
  - NEVER use next to vertical surfaces (for example, walls and dressers).
- (3) When product was placed on a soft surface and tipped over.
  - NEVER use on a soft surface (for example, bed, sofa, cushion).
- ALWAYS place child on back to sleep.

## Limited Warranty

Bergeron by Design warrants to the original retail purchaser of the Keekaroo® product, that if any part or component proves defective in material or workmanship within five years of the purchase date, the defective part will be repaired, replaced, or refunded at the discretion of Bergeron by Design.

This warranty does not cover normal wear and tear, or damage caused by accident or misuse and only applies in the United State and Canada. Any use of the product outside the US and Canada will void the limited warranty. Users outside the United States and Canada must contact the original retailer for their return or refund policy.

To exercise this limited warranty in the United States and Canada, the user should first obtain a Return Authorization Number from the retailer the Keekaroo® product was purchased from. The product must be delivered with charges pre-paid (UPS recommended) to the factory or to the retailer, together with a copy of the original invoice, the Return Authorization Number and a written description of the problem.

## Customer Service

Contact your retailer directly. Or contact us directly:

Keekaroo® Customer Service Support

Toll Free: 1 (800) 994-2416

International: 1 (315) 429-7110

Fax: 1 (315) 429-8862

Email: Support@Keekaroo.com

## Notice

No part of this document may be reproduced or translated to another language without the prior consent of ©Bergeron by Design.

Use only Keekaroo® accessories and parts on Keekaroo® products. Keekaroo® parts are not interchangeable with other manufacturers' products. Replace any worn parts immediately for safety.

© Bergeron by Design 2017



Bergeron By Design  
15 South Second St.  
Dolgeville, NY 13329  
1.315.429.7110

